

BLUETOOTH INSTRUCTIONS

Bluetooth Headphone Pairing Instructions for the Ultraprobe 15,000

1. Turn on the Bluetooth headphones.
2. Turn on the Ultraprobe 15,000.
3. In the home screen touch the Bluetooth icon.
4. The Bluetooth search screen opens and the Bluetooth search icon blinks.
5. Touch the Bluetooth search icon (Magnifying glass) the search magnifier will blink. When the headphones have been located, the identifier number will show in the panel and the Bluetooth icon will display a check mark.
6. Press the Bluetooth icon with the checkmark
7. The PIN number will be shown as 0000.
8. Press okay
9. The screen will change; you will see a *next to the headphone PIN.
10. Press exit and begin using the headphones.

Bluetooth pairing instructions for all other Ultraprobe models.

In order to use the UE –DHC-2BT Bluetooth headphones, you must pair it with the Transmitter (DHC 2BT-TM)

NOTE: The transmitter must be fully charged for at least four hours before use.

1. Attach the transmitter to your Ultraprobe using the supplied Velcro pads and insert the transmitter plug into the headphone jack of your Ultraprobe.
2. Turn on the headphones (the “ON” light will illuminate Blue)
3. Press and hold the transmitter button for 3 seconds. It will initially light up red and then flash blue/red while searching for the headphones.
4. When paired, the blue light flashes once every 10 seconds.
5. When in standby or when disconnecting, the blue light will flash twice every five seconds.
6. When the battery charge is depleted the transmitter button will flash red.

Transmitter Charging Instructions:

1. Plug the USB into the Transmitter charger and the mini-USB into the Transmitter.
2. Plug the charger into an appropriate electric receptacle.
3. While charging, the transmitter light will appear a steady red. When fully charged the red light will turn off.

If you have any questions contact us:
UE SYSTEMS INC.

14 Hayes Street, Elmsford NY 10523 USA
Toll Free – 800.223.1325
Phone – 914.592.1220
Fax – 914.347.2181
Email – info@uesystems.com